













**PARTS INCLUDED:**

- 1 Horizontal Brace
- Top Pulley Brace
- Bottom Pulley Brace
- Metal Upright
- Weight Carriage
- Weight Peg Crossbrace
- 2 Spring Clips
- Straight Bar Attachment
- Lat Pull-Down Attachment
- 6 Pulleys
- 2 Plates for Pulleys
- 2 Pole Tubes
- 6 Carabiners
- 2 Cables
- Rubber Foot

**HARDWARE INCLUDED:**


<p>3 In Bolt x 9</p> 	<p>2 In Bolt x 3</p> 	<p>1.125 In Bolt x 2</p> 	<p>.75 In Nut x 12</p> 
<p>Black Spacer x 6</p> 	<p>.875 In Washer x 24</p> 	<p>.75 In Washer x 4</p> 	<p>.5 In Nut x 2</p> 



Any issues? Please contact us directly by phone: 720-420-1731, email: [info@repfitness.com](mailto:info@repfitness.com) or morse code...(-. .-. .-. .-. .-. .-. .-. .-.). We are always here for our Customers! - Team REP. Denver, Colorado

5.


Secure metal upright to pulley braces already attached to power rack.



- (3 in) x2
- (.875 in) x4
- (.75 in) x2

6.


Attach pulleys to their designated spots (there should be two that are not being attached yet as they need the cable to be secured).



- (3 in) x8
- (2 in) x1
- (.875 in) x16
- (.75 in) x8
- (.75 in) x8

7.

Feed cables through pulleys and secure the last two pulleys in their designated location. One end of each cable will attach to the base of the lat pull down to create a line of tension and the other will have a carabiner to attach pull-down accessories.



- (2 in) x8
- (.875 in) x16
- (.75 in) x8

8.

Clip your pull-down accessories to the carabiners.

